Refer to Waveform and Voltage Test Conditions.





Instrument HORIZ MODE to A INTEN



Test scope trigger SOURCE to CH 1

Test scope trigger SOURCE to CH 1



Test scope trigger SOURCE to CH 1



Test scope trigger SOURCE to CH 1

2237-120