

TP217 \emptyset V (uo)

TP215 3.3V (ov)

TP211 \emptyset V

TP216 \emptyset (uo)

TP209 3.3V

TP213 \emptyset

TP214 3.3V


TP212 3.3V

TP208 3.3V

TP210 \emptyset

C204 3.3V .45V

TP207 \emptyset



TP206 2.479V

TP205 \emptyset

CR201 \emptyset -V -3.3V

TP204 3.3V

TP208 3.3V

TP202 3.3V

* Voltage Readings
reference
are measured with
at

TP201 3.3V

the "-" battery terminal