



Notes:

1. SW1 Connected as Switch is depressed. All other switches connected as unpressed. Output should equal 120VAC at J2 Outlet
2. SW1,2,3 – Interlock Push Button Switch Piano Type DPDT 6 Pin, 4 row (Only 3 used)