




ADC




3V3 GENERATION




PWM




DISPLAY




BUZZER



ENCODER




RTC




HEADERS



TEMP SENSE



HANDLE



Quecoo T12-958 HW version V3.20
Traced schematic – may contain errors
25/05/2024
Release V03