




ADC




3V3 GENERATION




PWM




DISPLAY




BUZZER




TEMP SENSE



ENCODER




RTC



HEADERS



HANDLE



Quecoo T12-958 HW version V3.20
Traced schematic – may contain errors
02/06/2024
Release V04