
Fluke Flash Tool
FLUKE
Version 4 Firmware Upgrade
199/196/192
For use with ScopeMeter® 190 Series
For upgrading version 3.x to version 4.0 only
Adds automatic rise time measurement
Adds advanced waveform mathematics
Adds A vs. B waveform display mode (X-Y mode)
Instrument: DM
Com port: COM1
START
HELP
EXIT
Fluke Flash Tool Help
Select the Com port to which the ScopeMeter is connected
Connect the ScopeMeter to mains power using the BC190 Battery Charger
Turn on your ScopeMeter
Press the START button to start the upgrade process
When the upgrade is successful, a message is displayed. Note that your instrument will switch off and on several times automatically during the upgrade process.
If the upgrade fails:
If the upgrade is unsuccessful, sometimes the instrument is unable to start properly. In this situation the display will not switch on, and only a beep indicates that the instrument is on.
Turn on your instrument and listen for the beep. Now restart the upgrade process. The Flash Tool will recognize that the previous installation failed, and recover the instrument data automatically.
English
ABOUT
CLOSE