


Upgrade Instruction



Auto Update software V3.4 can be used to upgrade the models and the batch No. below:

- SDS6062: 1138xxx、1147xxx、1202xxx To V2.7.2.4
1210xxx、1217xxx、1237xxx To V2.8.6
1245xxx、1247xxx、1301xxx、1309xxx、1330xxx、1356xxx、1408xxx To V3.5
- SDS7102: 1122xxx、1127xxx、1137xxx To V2.5.1.*
1143xxx、1149xxx、1152xxx、1153xxx、1203xxx、1209xxx To V2.8.1.6
1211xxx、1219xxx、1223xxx、1234xxx、1240xxx、1246xxx、1251xxx、1303xxx、
1312xxx、1319xxx、1327xxx、1334xxx、1344xxx、1352xxx、1407xxx、1414xxx、
1418xxx To V3.8
- SDS8102: 1128xxx、1137xxx、1143xxx、1149xxx、1153xxx、1203xxx To V2.4.0.*
1211xxx、1219xxx、1223xxx、1239xxx、1249xxx、1313xxx、1319xxx、1320xxx、
1335xxx To V2.8
- SDS8202: 1128xxx、1137xxx、1143xxx、1149xxx To V1.4.0.*
1152xxx、1153xxx、1201xxx、1203xxx To V1.4.0.*
1211xxx、1219xxx、1223xxx、1238xxx、1249xxx、1313xxx、1320xxx、1335xxx
To V1.9
- SDS8302: 1221xxx、1229xxx、1323xxx To V1.4.2
- SDS9302: 1218xxx、1229xxx、1323 To V1.5.1


Upgrade steps:

1. Start the machine, connect the USB cable, and confirm that the USB driver has been installed (the installation software will install the drivers automatically, if the installation fails, you should install the USB driver manually).
2. Run the Auto Update software, click the **START** button. When the prompt appears as below, **restart the machine manually**. After the restart, it will enter the USB download mode automatically and be upgraded.






- 3 If the prompt appears as below, the upgrade is already done. If the machine does not restart automatically, restart the machine manually.




Upgrade the machine language switching instructions:

After the upgrade machine language by default for Chinese, press the "Utility" key to enter the following interface



Next, press the "H2" key to enter the language selection screen



Finally, the adjustable knob to choose the language to English

