

www.tektronix.com

TDS5000 Series Operating System Restore



063-3509-01

Tektronix

COMPUTING TELECOM VIDEO

CD ROM

Tektronix

TDS5000 Series
Operating System Restore

063-3509-01

www.tektronix.com

To restore the oscilloscope system software, do these steps:

1. If a keyboard is not installed, connect one to the instrument (the optional-accessory keyboard plugs into the USB connector on the rear panel).
2. Power on the oscilloscope.
3. Insert the *TDS5000 Series Operating System Restore* compact disc in the CD-ROM drive on the right side of the instrument, and close the CD door.
4. Hold down the **CTRL** and **ALT** keys, and the press the **DELETE** key. Repeat this procedure to reboot the oscilloscope.
5. The install program will start; follow the on-screen instructions to rebuild the operating system software. (Accept the *PowerQuest Easy Restore* license agreement.)
6. When the operating system restoration is complete (this requires 10 to 15 minutes), the oscilloscope displays a prompt stating that the computer needs to reboot to complete the process. Remove the *TDS5000 Series Operating System Restore* compact disc from the CD-ROM drive, and then press **Enter** to reboot.
7. Return your *TDS5000 Series Operating System Restore* compact disc to safe storage.

8. Now you need to install the oscilloscope software and any application software that you want to use. For instructions, refer to the booklet for the *TDS5000 Series Product Software* compact disc.